



The world's favourite lock

Installation Guide



Congratulations on purchasing your new Yale Doorman digital door lock

You have just purchased the most convenient and secure digital door lock on the market.

Yale has been a leader and pioneer in the residential door lock market since 1843 when Linus Yale first patented his revolutionary designs for a cylinder lock.

Ever since then Yale has been developing innovative new locking solutions around the World that meet the needs of today's busy households.

Yale understands the importance of combining the peace of mind that comes from having a proven high security lock with the benefits of having a genuinely convenient locking solution. Your Yale Doorman Digital Door lock has been rigorously tested in the severest weather conditions and has been developed in accordance with the exacting Scandinavia door lock standards.

With our hectic and demanding lifestyles Yale knows how important it is that locking your home is made as easy and convenient as possible. Yale Doorman has been designed with you in mind, whether you just want the freedom not to have to carry a key or you want the ability to quickly and easily control who can or can't enter your home.

We are convinced that once you have experienced the flexibility and convenience of your new Digital door lock you will never want to go back to carrying a bunch of keys again.

Welcome to the world of Yale Doorman Digital door locks – unlock your life.



Tryck in låset i dörren, se bifogad mall så det stämmer med din dörr



Skyv låsen inn i døren, pass på at kabel kommer ut av øverste hull på innsiden




Tryck in låset i dörren, se bifogad mall så det stämmer med din dörr




Insert the lock to the door, see attached template

Utsida / Utsiden / Utsida / Outside




Vänsterdörr / Venstre dør sett fra innsiden / Venstre dør / Left door


Innsida / Innsiden / Indvendig side / Inside



Eller / Or



Utsida / Utsiden / Udvendig side / Outside



Högerdörr / Høyredør sett fra innsiden / Højre dør / Right door



Montering av slutbleck



Montering av sluttstykke i karm



Montage af slutblik




Mounting of strike

Placering av slutbleck i förhållande till låshus

Plassering mellom sluttstykke og låskasse

Placering af slutblik i forhold til låsekasse

Positioning of strike in relation to lock





Ställ in för vänsterdörr



Innstilling for venstre hengslet dør



Indstilling for venstre dør



Set for left door



Ställ in för högerdörr



Innstilling for høyre hengslet dør




Indstilling for højre dør



Set for right door


Utsida / Utsiden / Udvendig side / Outside

Insida / Innsiden / Indvendig side / Inside



Utsida / Utsiden / Udvendig side / Outside

Insida / Innsiden / Indvendig side / Inside



Eller / Or



Sätt dit utsidan




Sett på plass



Placer det udvendige skilt på døren med den dobbelt klæbende tape



Mount the outside



Skruva ihop utsidan med insidans plåt




Skru sammen utvendig skilt med innvendig monteringsplate




Skru det udvendige skilt sammen med den indvendige montage plade




Fasten the outside with the inside plate



-  Anpassa vredpinnen
-  Tilpass lengde på medbringer
-  Tilpas vrider pinden
-  Adjust the length of the follower



-  Koppla in sladdarna på insidan
-  Koble til kabler på innvendig skilt
-  Isæt kabler på indersiden
-  Connect the cables to the inside





Montera fast insidan



Montere innvendig skilt



Monter det indvendige skilt med medfølgende skruer



Fasten the inside



Sätt i batterierna och fjärrkontrollmottagare som är tillbehör






Sette inn batterier og fjernkontrollmottakere som er tilbehør



Indsæt batterier og fjernbetjening modtagere som er tilbehør



Insert the batteries and accessory remote control receiver





Registrera kod



Legge inn masterkoden



Programmer masterkode




Register code

Slå koden, 6-12 siffror

Legg inn masterkoden, 6-12 siffrer

Indtast ny masterkode, 6-12 cifre

Enter your code, 6-12 digits




Bekräfta med **P** knappen

Bekreft med **P** knappen

Bekræft med **P** knappen

Confirm with the **P** button





Ställ in språk



Velg språk



Vælg sprog




Select language

Tryck # kod (6-12 siffror) #

Trykk # masterkoden (6-12 siffer) #

Tryk # efterfulgt af masterkode (6-12 cifre), bekræft med #

Push # code (6-12 digits) #




Tryck 1 (språkinställningar) bekräfta med #

Trykk 1 (språkinstilling) bekreft med #

Tryk 1 for sprogindstillinger, bekræft med #

Push 1 (language settings) confirm with #




Tryck 3 för svenska, bekräfta med #

Trykk 2 for Norsk språk, bekreft med #





Tryk 1 for Dansk, bekræft med #

Tryk 4 för engelska, bekräfta med #



-  Skruva fast luckan
-  Skru på batterideksel
-  Skru batteridækslet fast med medfølgende unbraco nøgle
-  Fasten the battery cover

-  Klart
-  Ferdigmontert
-  Klart
-  Done





The world's favourite lock

YALE, with its unique global reach and range of products, is the world's favorite lock – the preferred solution for securing your home, family and personal belongings.

ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience.